

Contents

	<i>Preface</i>	ix
	<i>Introduction</i>	xi
One	<i>Principles of Operation</i>	1
Two	<i>The Air Supply</i>	10
Three	<i>Combustion</i>	14
Four	<i>Fuel Injection</i>	17
Five	<i>Governors</i>	23
Six	<i>Cooling</i>	26
Seven	<i>Exhausts</i>	30
Eight	<i>Cleanliness is Next to Godliness</i>	32
Nine	<i>Troubleshooting, Part One—Failure to Start</i>	40
Ten	<i>Troubleshooting, Part Two</i>	54
Eleven	<i>Overhauls, Part One—Decarbonizing</i>	64
Twelve	<i>Overhauls, Part Two</i>	94
Thirteen	<i>Marine Gearboxes</i>	111
Fourteen	<i>Engine Installations</i>	118
Fifteen	<i>Engine Selection</i>	127
Appendices	A <i>Tools</i>	137
	B <i>Spare Parts</i>	139
	C <i>Useful Tables</i>	141
	<i>Glossary</i>	145
	<i>Index</i>	149